

IDEAPAINT INSTALLATION TIPS FOR SOUTH AFRICAN APPLICATIONS

COVERAGE

50SQF will cover 4,5 m2 200SQF will cover 18 m2 Do not exceed recommended coverage

PRIMING

When coating a new drywall / non-latex coated surface or repairing a surface, priming is required.

Proven locally available primers -

IdeaPaint Primer Clear / White (exclusive at The Write Co) Plascon Universal Undercoat, Dulux Plaster Primer,

Prominent Paints Ultra Primer

Apply IdeaPaint over eggshell, semi-gloss or gloss latex paint only. No matte or flat paints. Latex (acrylic) paint **must be water based**.

Proven locally available paints -

FOR CREATE WHITE	FOR CREATE CLEAR (GLOSS ONLY)
Plascon Wall & All	
Plascon Double Velvet	
Plascon Velvaglo WATERBASED	Plascon Velvaglo WATER BASED
Dulux Luxurious Silk	Dulux Luxurious Silk
Dulux Pearlglo	
Prominent Paints Ultra Sheen	Prominent Paints Ultra Sheen
Midas 230 or 240	Midas 240 (only)

PREPARATION

The IdeaPaint surface will only be as smooth as the surface it's applied to. Ensure that the surface is free of any holes or imperfections (thus repair where necessary).

Allow the last coat of paint to dry 24 hours, then sand smooth with 120 grit sandpaper to remove any debris that may have been collected during the process. Wipe with a **CLEAN**, dry or damp cloth. Wait for dust in area to settle before applying IdeaPaint as any dust particles will stick to the surface.

SITE & SURFACE CONDITIONS

All surfaces must be clean, dry and free of any internal moisture.

Only apply IdeaPaint once all contractors are off site and the environment is sterile, as a wet IdeaPaint surface will attract debris and dust.

CURING TIME

Curing time is crucial. Do not write on the surface before the recommended time.

For CLEAR, wait a FULL 7 days.

For WHITE, wait a FULL 5 days.

info@thewritecompany.co.za | t: 021 447 0966 | www.thewritecompany.co.za

